

Quick Start Guide

System Requirements

The following is a list of the minimum system requirements for the effective use of the software:

- Windows XP, Vista, 7, 8, or 10 (All versions, including both 32- and 64-bit). WinRT not supported.
- 1 GB Memory (RAM)
- 1.8 GHz dual-core processor or faster (ARM processor such as on Windows Surface running WinRT not supported)
- 1 GB available hard disk space
- Available USB port
- Available Internet connection and browser (for program installation and software updates)
- Screen resolution of 800x600 or greater
- Microsoft® .NET Framework 3.5 sp1 (free download). Not required with Windows 7. In Windows 8 and 8.1, enable this option through Control Panel | Programs | Turn Windows features on or off.
- Adobe Acrobat Reader (for reading and printing documentation)

Installation

WARNING: Do NOT use a power inverter to power your computer via the car's 12 Volt system when using this tool.

1. Open your Internet browser and go to <http://www.bavariantechnic.com/download.aspx>.
2. Click the *Bavarian Technic version x.x.x.x* link to start the Bavarian Technic software installation. If prompted to save the file, note the saved location and run the installation by double-clicking the saved file.
3. Step through the installation wizard as prompted until the software and included USB cable drivers are successfully installed.
4. Turn your car's ignition to the accessory position II (or equivalent) to power the components of your car.
 - If your car is a 2005 or newer model, turn the car's hazard lights on (emergency flashers) for the duration of diagnostics. Doing so keeps the car's CAN bus awake.
5. Connect the Bavarian Technic cable to the diagnostic port in your car.
 - On cars prior to model year 2002, use the 20-pin early model adapter cable to connect the Bavarian Technic cable to the car's round data link connector ("DLC") found in the engine bay.
6. Connect the Bavarian Technic cable to the USB port on your computer. Allow a few moments for Windows to install the cable hardware.
7. Confirm the LED light on the Bavarian Technic cable is steady green.
8. Launch the Bavarian Technic software program by double-clicking the desktop icon.

For more information on using the tool see the complete user guide at: www.bavariantechnic.com/download.aspx.